




Collapsible Water Bottle



PRODUCT USE AND CARE

© 2020 Nomader, Inc. All Rights Reserved.

Thank You

Thank you for your Nomader water bottle purchase. This guide provides you with important tips on how to get the most out of your new bottle. You can access the digital version of this and other helpful info at nomader.com/help

As a small growing business, our happiness hinges on your happiness. So if you ever need help or have feedback, drop us a line at support@nomader.com or call 1.800.213.7052.

Happy hydrating!



Bryan Sarlitt

Founder of Nomader



Maintaining a Fresh Taste

1) Before first use (to remove any initial "new bottle smell")

fill your bottle with boiling water, add 2 tablespoons of lemon juice (optional: add 2 tablespoons of baking soda), soak overnight, rinse with cold water. Repeat as needed.

2) Keep your bottle fresh by cleaning on a regular basis with any of these methods (even if just drinking water):



BOTTLE BRUSH (preferred method)

Use a soft-bristled bottle brush with hot dish soapy water to scrub the bottle's interior and lid/cap, rinse thoroughly and air out to dry.



CLEANING TABLETS

When traveling, hiking, or camping, water bottle cleaning tablets are a convenient way to keep your bottle squeaky clean.



HAND SHAKE

Fill half way with hot water and dish soap, close, shake vigorously, empty, rinse out thoroughly and air out to dry.



DISHWASHER

Place bottle on top rack with lid separated from the body. Secure the strap so it doesn't come into contact with the heating element.

- 3) Drop in some lemon juice for a healthy and refreshing flavor, and to help safeguard your bottle against bacteria.
- 4) Where possible, fill your bottle with fresh filtered water, available in most airports, hotels, restaurants and cafes.
- 5) Replace water that's stagnant in your bottle for several hours or days, especially in hot and humid environments.

Rolling-up Your Bottle

For a 5 second video demo, visit nomader.com/help

1

Empty bottle of any liquids
and loosen cap to release air.

Align "U" slots in plastic
sleeve so strap is on one side
and the cap's water drop
icon is on the opposite side.

2

Grip base of bottle and slide up sleeve
until the bottom inner edge of the "U"
meets the seam line in the silicone
body (below the plastic latch).




3

Using a flat surface for support, tightly roll up the base of the silicone body toward the plastic latch on the neck of the bottle.



4

Use one hand to hold the bottle in its rolled up position while you use your other hand to wrap the strap around to hook the strap clip to the plastic latch. Well done!



Opening and Closing

- To sip from your bottle, open the hygienic spout cover (cap) by twisting counter-clockwise.
- To refill your bottle, add ice, add fruit, or to clean, open the wide mouth lid by twisting counter-clockwise.
- To close your bottle, ensure that both the spout cover and lid are fully tightened by twisting clockwise. Test for leaks by holding your bottle upside down and shaking.



SPECIFICATIONS

- Capacity: 25oz (740ml) | Volume markings: 22oz (650ml)
- Weight: 7.2oz (204g) | Height: 27cm | Diameter: 7.4cm
- Rolled-up dimensions: 12.7cm x 10.8cm x 9.5cm
- Materials: 100% BPA-free silicone and PP (Polypropylene)

PRECAUTIONS

- Rated for temperatures of -4°F to 248°F, Nomader bottles are safe to freeze and safe to use for hot beverages.
- Always use the hard plastic sleeve when handling hot liquids to help insulate your hand from the heat.
- Do not microwave. Doing so will void your warranty.
- When using a dishwasher, place bottle on top rack and secure the strap so it doesn't touch the heating element.

Lifetime Warranty

At Nomader, we proudly stand behind the quality of every water bottle we make. To show our commitment to quality, we offer a lifetime warranty that covers the repair or replacement of manufacturing defects for the lifetime of the bottle.

To learn more about our lifetime warranty policy or to file a claim, please visit nomader.com/warranty

We also offer a 100% satisfaction guarantee. If you're not totally happy with your Nomader water bottle, simply return it to us within 90 days of purchase for a full refund or exchange.

For return instructions, contact us through the form on our help page at nomader.com/help

